

Digital Scale User Manual

Thank you for choosing our digital scale, which scale is designed base on the environmental philosophy, please read the user manual carefully before use it.

Parameter

Auto Power Off: 3 Minutes(adjustable)

No shut off Using USB power

Operation Temperature: 0-35 °C

LCD Display: 6 digits LCD Display

Back light: Green (Optional)

Power Supply: 2XAAA Batteries or USB

Dimension: 120X67X17.5mm

Net Weight: 88.4g

Salver size: 66x59mm

Tare Function

Counting Function

Low Power Indicator

Unit: g/oz/ozt/dwt/ct/t/gn ("J" unit can choose or remove the unit.)

Operation Instruction

Put the Scale on the stable & windless place with 2XAAA batteries or USB connection.

1. Press "ON/OFF", it displays 0.00 after 3 seconds.
2. Put the article on the tray, it reading the result of the article when the unit stop flashing.
3. Press UNIT to change the weighing unit.
4. Press TARE gently can be tared
5. Press COUNT for counting function.
6. Press ON/OFF to power on or power off.
7. Calibration function

Press "ON/OFF" about 3 seconds till it display "0", then release the button, It shows a weight value(such as 500.0), put the 500g weight on it(can press TARE to change the weight value), it flashes till displays the weight value. The calibration is completed. (please do calibration if the scale cannot give correct reading because of temperature difference or other reasons.)



8. Counting operation

At weighing mode 0.00, get 25, 50, 75 or 100pcs as sample, put the sample on the weighing pan and display the value, then press "PCS" 3 seconds it will display P25PCS(P50,P75, P100), press "UNIT" to choose the sample quantity value, press COUNT button for confirming, it will display the quantity of the weighing article, press COUNT again to return counting mode, it shows PCS, now can add the quantity of the weighing articles to count.

9. Setting the units display function(J unit)

It use different weighing unit in different country, some unit is not necessary, You can shield the useless unit. Press UNIT 3 seconds to activate all the units, press UNIT again to choose the useless unit, press TARE to confirm or remove the unit. Press UNIT again to choose the next one then press TARE again for confirm. Press UNIT 3 seconds to complete the unit choosing and return to the tweighing mode. Press UNIT to verify the units quantity. Do the above steps again for re-setting.

10.Set automatic shutdown time

Effective in battery mode! External USB mode does not work. At work on state, press the "TARE" key 3 seconds to LCD display "RU X" (eg. "RU 60, it means it will automatic shutdown in 60 seconds"), press "MODE" to change the size of the value of X, press "TARE" to confirm.

Unit Conversion

1. Please use the scale in stable & windless place
2. Never put on the tray the weight over the rated one, otherwise the sensor part will be damaged. When applying the article, please conduct it gently.
3. Do not making the phone call in a range of 50 com when using the product, or it will affect the result.
4. Read the weighing value when the units symbol stop flashing.
5. Please change the battery when the battery symbol flashing, the scale will power off.
6. Please use the product in 0-30 °C , big temperature difference may cause error. If temperature difference is noticeable, please do the calibration, Please guarantee the product work on over 30 minutes when doing the calibration.
7. It will display "FULL" when overload.

Tare care of the Scale and Do not disassemble.

This product has been patented, and copying is not permitted. Patent

No.:201530555010.7